



--	--

Interior Elevation Notes

1. SHADING ON FRONT OF CABINETS INDICATES SHINGLES BASED ON 1/2" SHINGLES. CABINET TOPS AND COUNTER MUST BE COMPARABLE TO SUPPORTING FIN. 20201 AT FRONT COUNTER EDGE. (SEE DETAIL 3.18.24)
2. EXTEND FLOOR FINISH AND BASE MATERIAL INTO KITCHEN. EXTEND 1/2" MIN.
3. INSIDE FACES OF ALL CABINETS SHALL BE UNPAINTED.
4. PROVIDE PLASTIC LAMINATE ON ALL EXPOSED SURFACES.
5. PROVIDE CHROME CONCEALED SELF-CLOSING HINGES.
6. PROVIDE SATIN STAINLESS STEEL FULLS.

NOTE: ALL COUNTERTOPS DEAD ENDING INTO WALLS SHALL HAVE A 1/2" DEEP GRAB BAR.